

## Test Plug

Testing and make troubleshooting by connecting terminal blocks.



Type	TPS 2.0	TPS 2.3	TPS 4
Diameter(mm)	Ø2.0	Ø2.3	Ø4
Terminal Model	CDU 2.5	CDU 2.5 CDU 4 CDU 6 CDU 10	CDU 6 CDU 10 CDU 16 CDU 35

## Socket



Type	TP 2.0	TP 2.3	TP 4
Terminal Model	CDU 2.5	CDU 2.5 CDU 4 CDU 6 CDU 10	CDU 6 CDU 10 CDU 16 CDU 35

## Tool-Screw driver



Type	DS 3	DS 4	DS 5	DS 6	DE 6	DE 8	DK 5	DK 6	DK 8
Terminal Model	CDU 2.5 CDU 4  CPE 2.5 CPE 4  CDK 2.5 CDK 4  CTR 2.5 CTR 2.5D CTR 4 CTR 4D CTR 4SI  SDU 2.5 SDU 2.5/3 SDU 2.5/4 SDU 4 SDU 4/3 SDU 4/4  SPE 2.5 SPE 2.5/3 SPE 2.5/4 SPE 4 SPE 4/3 SPE 4/4	CDU 6 CDU 10  CPE 6 CPE 10  CDK 6 CDK 10  CTR 6 CTR 6D CTR 6SI CTR 10 CTR 10D CTR 10SI  SDU 6 SDU 6/3 SDU 10 SDU 10/3  SPE 6 SPE 6/3  CTL 6 CTL 6-1	CDU 16  CPE 16 CPE 50  SDU 10 SDU 10/3  SPE 10 SPE 10/3	CDU 35  CPE 35 CPE 95	CPE 50	CPE 95	CDU 50	CDU 95	CDU 150